


BASE PLATE- BC-01 (BOBCAT BASEPLATE)



DOOR BAR- (NQD-080) STANDARD

HANDLE PIVOT- (NQD-075) STANDARD

HANDLE- (NQD-092LH) LONG

DOOR- NQD-BC5261

CENTER DEFLECTOR- (NQD-100) STANDARD

BRACKETS- BC-08 BRACKETS (UNINSTALLED/WITH HARDWARE KIT)

HARDWARE KIT- BC CONTENTS:


(6) 5/16-18 X 1 BOLTS WITH (12) SAE WASHERS/(6) NYLOCKS

(4) ¼-20 X 7/8 CAP SCREWS WITH (4) GRADE8 NUTS

(1) SPRING/(1)SPRING PULLER

(2) **BC-08** BRACKETS

BAFFLE/SUBPLATE- BC-04, (L-SHAPED STEEL DOOR BAFFLE)




- STEP 1 REMOVE FACTORY CHUTE
POSITION QWIKCHUTE ASSEMBLY ON MOWER DECK
WITH ANGLE CLIPS ON BOTTOM OF QWIKCHUTE
BASE PLATE ATTACHED TO DECK EARS AS SHOWN
USING SUPPLIED 5/16 BOLTS, NUTS AND FLAT WASHERS
- STEP 2 DOOR TO BE TIGHT AGAINST DISCHARGE FACE WHEN
TIGHTENING BOLTS AND NUTS.
BOLTS ATTACHING ANGLE CIP TO QWIKCHUTE
BASE PLATE TO BE TIGHTEN AT FINAL ASSEMBLY
ADJUST DOOR BAFFLE TO CLEAR DECK RIB,
TIGHTEN HARDWARE (SEE PICTURE 1)
- STEP 3 INSTALL SPRING (SEE SPRING INSTALLATION SHEET)
- STEP 4 INSTALL HANDLE

INSTALLATION OF QWIKCHUTE NQD-BC5261 BOBCAT 52" AND 61"

DATE: 02-06-2013
REV. C 06-13-2019
FILE: BC06.DWG

X	X
NQD-BC5261	NQD-BC5261
NEXT ASSY	FINAL ASSY
DWG.	BC-06
DRAWING NUMBER/PN	


USE THESE SLOTS TO MOUNT
QWIKCHUTE BASE TO ANGLE CLIPS
USING SUPPLIED 5/16 BOLTS, NUTS AND
FLAT WASHERS



INSTALLATION OF QWIKCHUTE
NQD-BC5261 BOBCAT 52" AND 61"

DATE: 4-13-2011
REV. B 12-19-2017
FILE: BC03.DWG



X	X
X	X
NQD-BC5261	NQD-5261
NEXT ASSY	FINAL ASSY



PICTURE 1

SPRING INSTALLATION QWIKCHUTE NQD MODEL

STEP 2 LOOP FINGERS OVER SCREWDRIVER
BLADE AND LIFT SPRING ON TO SPRING BOLT
CAUTION -DO NOT OVER STRECH SPRING
DISCARD WIRE LOOP AFTER SPRING IS CONNECTED



HANDLE INSTALLATION AND ADJUSTMENT

QWIKCHUTE OPERATING PRECEDURE

OPEN FULLY- move handle away from operator quickly.

CLOSE FULLY- move handle toward operator quickly.

PARTIALLY OPEN- from close position move handle away from operator until stay bar swings into position and release handle. To close from partially open position, quickly open and then close.

(some models do not have partial open feature.)

OIL ALL BEARING POINTS WEEKLY OR AS NEEDED.

WARRANTY

GTM Manufacturing, Inc. products are warranted to the original purchaser to be free from defects in materials and workmanship for a period of 90 days from the date of purchase.

Any part(s) of GTM products found to be defective within the warranty period shall, at GTM's option, be repaired or replaced without charge.

Warranty consideration is obtained by returning any GTM product/part believed to be defective to GTM Manufacturing, Inc. within the applicable warranty period. **Please call for authorization.**

GTM Manufacturing, Inc.

14350 EASTSIDE ST

GROVELAND, FL. 34736

(407) 654-6598

www.qwikchute.com

Warranty does not apply to conditions resulting from:

1. Damage(s) and/or costs associated with shipping and or/ transportation.
2. Lack of normal maintenance, adjustments, or service required for regular use of the product.
3. Modifications, service/repairs, parts or components not authorized by GTM.

GTM shall not be liable for any special, consequential, direct or indirect damages, and expressly states there are no implied warranties. Some states do not allow limitation of incidental or consequential damages, accordingly the above limitations and exclusions may not apply to you. This warranty provides you with specific legal rights which may vary from state to state.

IT IS THE OWNERS RESPONSIBILITY TO PROPERLY COMPLETE AND MAIL THE WARRANTY REGISTRATION CARD.

PROOF OF PURCHASE AND REGISTRATION WILL BE REQUIRED IN ORDER TO OBTAIN WARRANTY SERVICE.

WARRANTY REGISTRATION CARD

Name of Purchaser: _____

Street Address / P.O. Box: _____

City: _____ State: _____ Zip Code: _____

Model Number: _____ PURCHASE DATE: _____|_____|_____

Dealer Name: _____

Street Address: _____

City: _____ State: _____ Zip Code: _____

Customer Received: Operators Manual (☐) Safety Instructions (☐) Demonstration (☐)

Customers Signature

Date