

NQD-JDQTR61 KIT CONTENTS. INSPECTED BY: \_\_\_\_\_

BASE PLATE- STANDARD (**NQD-071**)

DOOR BAR- STANDARD (**NQD-080**)

HANDLE PIVOT- (**NQD-117**) OUT THE REAR (WITH JD-05, JDQTR61 HANDLE PIVOT EXTENSION)

HANDLE- STANDARD (**NQD-092**)

DOOR- NQD-JDQTR52 , NQD-JDQTR61

CENTER DEFLECTOR- STANDARD (**NQD-100**)

END DEFLECTOR- FULL

BRACKETS- (2) **UB-02** (1.666" TALL KUBOTA BRACKETS)

HARDWARE KIT- C



QWIKCHUTE KIT  
NPD-JDQTR61

## STEP 1

### NOTE:

- A** QWIKCHUTE TO BE INSTALLED WITHOUT SPRING QWIKCHUTE DOOR TO BE IN CLOSED POSITION AND PRESSED FIRM AGAINST MOWER DISCHARGE FACE BEFORE MARKING MOUNTING HOLES ON DECK, USE HOLES IN MOUNTING U BRACKETS AS TEMPLATE TO MARK CENTER OF HOLES ON DECK. REMOVE QWIKCHUTE AND CENTER PUNCH MARKED LOCATION AND DRILL 9/32" DIA HOLES THRU DECK
- B** SEE STEP 2 FOR MOUNTING HARDWARE


USE EXISTING  
HOLE IN DECK  
FOR THIS BOLT

## STEP 2

- (1) BOLT HEX HD 1/4-20 X 1" LONG
- (4) WASHER FLAT 1/4"
- (1) NUT HEX SELFLOCKING 1/4-20
- 4 PLACES
- A** WITH QWIKCHUTE DOOR PRESSED FIRMLY AGAINST MOWER DISCHARGE FACE TIGHTEN ALL MOUNTING HARDWARE.
- B** INSTALL SPRING (SEE SPRING INSTALLATION SHEET)
- C** INSTALL HANDLE (SEE HANDLE INSTALLATION SHEET)

QWIKCHUTE KITS  
NQD-JDQTR52 & NQD-JDQTR61

**STEP 2**    LOOP FINGERS OVER SCREWDRIVER  
BLADE AND LIFT SPRING ON TO SPRING BOLT  
CAUTION --DO NOT OVER STRECH SPRING  
DISCARD WIRE LOOP AFTER SPRING IS CONNECTED



# QWIKCHUTE OPERATING PRECEDURE

(some models do not have partial open feature.)

OIL ALL BEARING POINTS WEEKLY OR AS NEEDED.

# WARRANTY

GTM Manufacturing, Inc. products are warranted to the original purchaser to be free from defects in materials and workmanship for a period of 90 days from the date of purchase.

Any part(s) of GTM products found to be defective within the warranty period shall, at GTM's option, be repaired or replaced without charge.

Warranty consideration is obtained by returning any GTM product/part believed to be defective to GTM Manufacturing, Inc. within the applicable warranty period. **Please call for authorization.**

**GTM Manufacturing, Inc.**

**14350 EASTSIDE ST**

**GROVELAND, FL. 34736**

**(407) 654-6598**

**[www.qwikchute.com](http://www.qwikchute.com)**

**Warranty does not apply to conditions resulting from:**

1. Damage(s) and/or costs associated with shipping and or/ transportation.
2. Lack of normal maintenance, adjustments, or service required for regular use of the product.
3. Modifications, service/repairs, parts or components not authorized by GTM.

GTM shall not be liable for any special, consequential, direct or indirect damages, and expressly states there are no implied warranties. Some states do not allow limitation of incidental or consequential damages, accordingly the above limitations and exclusions may not apply to you. This warranty provides you with specific legal rights which may vary from state to state.

IT IS THE OWNERS RESPONSIBILITY TO PROPERLY COMPLETE AND MAIL THE WARRANTY REGISTRATION CARD.

**PROOF OF PURCHASE AND REGISTRATION WILL BE REQUIRED IN ORDER TO OBTAIN WARRANTY SERVICE.**

## **WARRANTY REGISTRATION CARD**

Name of Purchaser: \_\_\_\_\_

Street Address / P.O. Box: \_\_\_\_\_

City: \_\_\_\_\_ State: \_\_\_\_\_ Zip Code: \_\_\_\_\_

Model Number: \_\_\_\_\_ PURCHASE DATE: \_\_\_\_\_|\_\_\_\_\_|\_\_\_\_\_

Dealer Name: \_\_\_\_\_

Street Address: \_\_\_\_\_

City: \_\_\_\_\_ State: \_\_\_\_\_ Zip Code: \_\_\_\_\_

Customer Received: Operators Manual ( ☐ ) Safety Instructions ( ☐ ) Demonstration ( ☐ )

\_\_\_\_\_  
Customers Signature

\_\_\_\_\_  
Date